



Room Climate Station[THP]

Top in indoor measurement



Individual visualization in the browser.
Flexible use.
Easy handling by plug & play.



Station[THP] • For precise measurement of your room climate. Reliably measures temperature, relative humidity and air pressure.

- ✓ Measure precisely · with the high quality sensor “THP”
- ✓ Document professionally · with the data logger met[LOG], without software installation on your PC, tablet or smartphone
- ✓ Save permanently · with the software MeteoWareCS

Station[THP] • The economic replacement for traditional drum recorders: no consumable necessary, no more filing of paper documents!

- ▶ museums, galleries, libraries
- ▶ storage rooms
- ▶ paper, printing and textile industry etc.



The first step towards optimal room climate

Optimisation of the room climate starts with the precise measurement of temperature and humidity. A filter protects the measurement elements of our compact THP sensor from air pollutants, providing highest reliability and lowest maintenance.



Intelligent multitool for all room climate data

Our all-new compact data logger met[LOG] for easiest plug & play data management. The met[LOG] provides data by LAN or WLAN - just at a push of a button. Warnings and alarms, e.g. for customised ventilation and heating, protect humans, buildings and installations.

- ▶ Individually customisable visual output in your browser - without any software installation



Concentrated power · the all new power[cube], WLAN-Edition

This compact cube is a true powerhouse. Not only does it protect the met[LOG] from all climate impact, but also its power supply (24 V/150 W) and the WLAN router.

- ▶ Easy installation · universal application



Id-No. 00.08095.000000 THP sensor
Id-No. 32.14567.060000 12 m cable

Id-No. 30.95800.115000 power[cube] incl. met[LOG]
Id-No. 32.14629.010000 Wall bracket indoor for THP sensor